



**Instanta**  
**Supreme 3 & 6**

<b>SW13 &amp; SW13/6 Supreme - EXPLODED DRAWING KEY (D.19-SP)</b>			
<b>Drawing No</b>	<b>Description</b>	<b>Part No</b>	<b>Price (£)</b>
1	Heating element (3.0kw, 230V)	E280	65.47
2	Normal Operating Probe (Black wire)	PRB8/A	17.05
3	1/4" to 3/8" Brass Adaptor	FV305	3.61
4	Brass probe holder c/w "Overfill" level sensor (orange wire)	PRB4/A	17.05
5	Safety valve (set to blow @ 25p.s.i.)	SV202	72.47
6	Anti-vacuum & air release valve	V700/KIT	35.78
7	Water syphon pipe	H/TUBE3	19.11
8	Low-level sensing probe (yellow wire)	PRB3/A	17.05
9	Brass Elbow	H/FF113	9.14
10	Triac (used to switch power to heater(s) via a signal from PCB)	XE851 (3Kw) XE854 (6Kw)	15.83 24.44
11	Brass "T" piece	H/FF122	10.96
12	Braided Water and Steam Pipes	H/FF387	34.13
13	Safety "Trip" P.C.B.	FF851	37.39
14	Main P.C.B.	FF850	152.06
15	Steam dispense wand	DA105/A	68.17
16	Upper tap handle assembly	TP801	40.45
17	Draw-off tap body - Steam	TP800/S	79.64
18	Grey plastic tap collar	XEN303/HT	5.98
19	Water dispense arm complete	DA104/A	70.29
20	Water "aerator" spray & adaptor	H/FF102 & H/FF101	13.38
21	Draw-off tap body - Water	TP800	79.64
22	Pressure gauge	PG11	62.63
23	ON/OFF switch	XEN400	12.11
24	Over-ride pressure-switch (purple wires)	EN266N	38.17
25	Mains pressure-switch (orange wires)	EN264N	38.17
26	Brass flare fitting for pressure switch	H/FF132N	6.74
27	Capillary tube(s) to pressure switches	E270B	17.35
28	Lower water inlet pipe (5/16" copper)	Ring Spares	
29	1/2" to 1/4" brass reducer	BV20	9.12
30	Pressure reduction valve	PR5	70.93
31	Solenoid inlet adapter	SA14/IN	10.42
32	Solenoid valve	SOL14	31.67
33	Solenoid outlet adapter	SA14/M	10.42
34	Non-return valve	NR52	26.32
35	1/2" to 1/4" female adapter	B507	7.01
36	Brass Elbow	H/FF113	9.14
37	Upper water inlet pipe (5/16" copper)	Ring Spares	
38	Complete Inlet Assembly	Ring Spares	
Not shown	6-hole tank gasket	B225	15.15
	8-hole tank gasket	H/FF127	14.14
	13-hole tank gasket	H/FF128	15.34